PPE Removal Checklist for PAPR

• **In the patient room, there should be hand sanitizer and a waste container** • **Use this poster as a guide to doffing safely** • **If available, wait until a trained observer indicates that they are ready to watch you perform doffing.**	
1. Sanitize gloves. Remove both gloves using glove in glove technique. Using a gloved hand, grasp palm of other glove and peel off slowly. Hold removed glove in the gloved hand. Slide a finger under the glove and peel off second over first glove. Discard in waste container.	
2. STANDARD TIE GOWN: **Sanitize hands. Unfasten gown ties, taking care that sleeves do not contact your body when reaching for ties.** **Pull hands into sleeves without touching the outside. Grasp hands onto inner sleeves to protect your hands.** **With protected hands reach up and remove the gown from the shoulders while rolling the sleeves inside out.** **Roll gown inward slowly so that the dirty sides are contained and roll into a ball. Discard in waste container. Discard soiled gown into hamper if needs to be laundered or if disposable then discard in waste container.** **3 ARM GOWN:** **Pull clean hands into sleeves. Next, you will remove the gown.** **Start by rolling the shoulder. Reach up and remove the non-dominate shoulder of the gown, not touching the inside of the gown or under the hood.** **Reach your other arm around your back and grab for the sleeve only. DO NOT touch your bare hand. Your sleeve will be inverted with clean surface outward.** **Using your dominate hand, pull the gown around to the front and grab the inside of the gown with non-dominate hand.** **Roll gown inward slowly so that the dirty sides are contained and roll the gown into a ball. Discard soiled gown into hamper if it needs to be laundered, or discard into waste container if disposable.**	
3. Sanitize hands; exit room.	
4. Sanitize hands. DO NOT TOUCH THE FRONT OF THE PAPR HOOD AS IT IS CONTAMINATED. **Reach behind your head, grasping hood where the hose connects. If able to disconnect hose without agitating the hood, do so. If not, then lean slightly forward and pull hood off without touching your scrubs. Follow cleaning instructions after disconnecting hose. Remove PAPR machine.**	
5. Sanitize hands. Apply new gloves and use appropriate cleaning wipe and wipe all of the surfaces of the PAPR machine, then place on charger.	
6. Perform hand hygiene with soap and water.	